

Section 5

Structural Measures — Temporary

Contents	Page
Straw Bale Dikes	5.3
Silt Fences	5.5
Check Dams	5.9
Temporary Stream Crossing	5.11
Construction Road Stabilization	5.14
Temporary Construction Entrance	5.16
Dust Control	5.18

Temporary Sediment Control Measures

General

These are temporary measures, with a short life expectancy, to control sediment and erosion. They should be used especially around construction sites and new developments. These types of sediment

control measures call for considerable maintenance and inspection. Maintenance of removing sediment after every storm is very important, along with replacing damaged materials.



Straw bales installed in a line to retard sediment runoff.



A silt fence will retard runoff until sediment has dropped out.